

Align Dotted line with top of console

- 
- 1) Align Dotted line with top of console
  - 2) Using one of the console spacers position the hole over the line for either port or starboard.
  - 3) Keeping the spacer lever drill the top holes on the console from 1-3" below the top of the console.
  - 4) Using a similar technique drill the second set of holes no less than 15" below the first set of holes.
- Note: before drilling holes in the console make sure there are no obstructions, wiring, fuel lines in the area.

Position the template on the opposite side of the console making sure the holes are in the same position across the console to allow the legs to be parallel to each other.

Use this line for port side alignment

Use this line for starboard side alignment

Use this line for port side alignment

Use this line for starboard side alignment