

INSTALLATION INSTRUCTIONS

TACO[®]
M A R I N E

UPHOLSTERY CLIP F16-0094

TOOLS REQUIRED:

Screwdriver, stainless steel screws with collars

ASSEMBLY:

- 1) Screw clips onto desired surface.
- 2) Hold the panel in place, so that the holes in the clips line up with those in the mounting surface.
- 3) Set the panel in place. Insert the screws through the collars, thread the screws into the screw holes just enough to hold the panel in place, Check the panel again for fit and placement.
- 4) Adjust the panel as necessary; tighten all the screws.
- 5) Insert upholstered panel into clips.

