

INSTALLATION INSTRUCTIONS

Before you get started:

When determining the locations for the Side Mount Outrigger Mounts on a vertical surface of your boat, such as an outside cabin wall, bulkhead or center console, make sure that you have access to the inside of that wall. If your bulkhead has double wall construction, you will need access to the inside of the outer wall. In some cases you will need to cut an access panel so you can attach the backing plate and to check for wiring or other components that may be inside the wall.

Once you have determined the desired location is accessible and free of other obstacles you can proceed with the instructions below.

With the arm facing aft, it should be mounted at an upward angle
TIP: *When the outrigger is in the aft position and extended, the tip should be no higher than the highest point of your boat.* This will prevent damage to your outrigger when going under low bridges. With the outrigger in the retracted position a line caddy should be used to keep tension on the line so the outrigger does not extend due to the motion of the boat. Outriggers must be in this retracted position facing aft when running.

Determine the length needed for your 5/16" stainless steel bolts. When determining the length, take into consideration the added length needed if you choose to use the optional spacers to bring the mount away from the surface. Purchase the bolts, nuts and washers before you begin the installation.



50 N.E. 179 Street
Miami, FL 33162
Tech Support: 800-653-8567
Fax: 305-770-2386
Email: info@tacomarine.com

TACOMarine.com

Installation:

1. *Have someone help you with this first step.* Insert the arm into the base with the arm facing aft. Completely extend an outrigger and place it in the arm. While someone is holding the outrigger, hold the base to the vertical location chosen and have your helper raise the outrigger until it is in an upward position, but no higher than the highest point of your boat.
2. Use a wax pencil to mark the locations of the 4 mounting bolt holes. *Make sure the area is accessible from the inside and free of wiring, bulkhead, etc.*
3. Drill the four mounting holes with a 5/16" drill bit.
4. Bolt the mount to the vertical surface using the stainless steel bolts, nuts, washers, lock washers and backing plate. Spacers can be used if needed to bring the mount away from the surface.
5. When you attach the second mount, on the other side of the boat, you want to match the positioning as close as possible to the installed mount. When installing the mount on an angle, the critical measurement is the placement of the topmost hole. Take careful measurements from different directions to insure that the topmost hole is in the same relative location as the first one you mounted.
6. Drill the topmost hole and insert a bolt through the mount and into the hole. Always angle the top of the mount towards the rear of the boat. Now install the arms and outriggers into both mounts and extend the outriggers. Have someone observe when the two outriggers are even, then mark the remaining holes with your wax pencil and remove the unit.
7. Drill the remaining holes and install the mount to the surface using the remaining bolts, nuts, washers, lock washers, backing plate and spacers if needed.

***Your Side Mount Outrigger Mounts
are now ready to use.***