

# INSTRUCTIONS

## Roof Rack P03-242, P03-244

Thank you for purchasing a quality Taco Marine product. Please follow instructions below for optimum use of your purchase.

- 1) Mount tubes on bases - use included nuts & bolts.
- 2) Mount on storage racks - either permanently with screws or temporarily with wire ties (both are included).  
**MATCH SCHEMATIC (UPPER LEFT) TO GET THE PROPER UNITS IN FRONT AND REAR**
- 3) To use - insert reel seat in rear tubes - drop rod in the forward unit and stretch shock cords over both to secure. (Shock cord must be placed in front of the reel on the rear unit)

### FEATURES

- Hi-density UV-stabilized polyethylene with Stainless Steel fasteners (no rust or corrosion)
- Mounts permanently or temporarily to all car carriers (mounting hardware included)
- Each unit safely and securely holds rods and reels - any type and size

