

## **ROD & REEL TOTE 'M RACK**

P03-144W

## **Installation Instructions**



## **INSTRUCTIONS**

- 1) Install ends (B) and (C) in the pre drilled holes in the base (A) use screws described in (D).
- 2) Mount bracket (E) to surface (horizontally or vertically) with screws described in (G).
- 3) To use bracket, match up the holes in handle (A) and in mounting bracket (E) and install pin (F).

Patent #6,267,425

## **Box Includes**

- BASE
- END PIECE FOR ROD BUTTS (REEL END)
- END PIECE FOR ROD TIPS
- 4 #8 X 5/8" O.H. STAINLESS SCREWS
- SHOCK CORD TO SECURE RODS
- MOUNTING BRACKET
- STAINLESS PIN
- 2 #8 X 1-1/4" PAN HD STAINLESS SCREWS

Required\*
\*not included

- ELECTRIC DRILL AND/OR PHILLIP'S HEAD SCREWDRIVER
- SAFETY GOGGLES







