



## Assembly Instructions

**Thank you** for purchasing the TACO Marine Walk-Thru Windshield Latch - Stainless Steel! As a family-owned and operated business since 1959, we take pride in offering the highest-quality, innovative products with excellent customer service. We stand behind our products 100 percent. If you have any questions about this mount or installation, please contact us by visiting [tacomarine.com/contactus](http://tacomarine.com/contactus).

### Box Includes

1. Align the latch and stud, with the stud located inside the closed latch, in the desired location.
2. Mark precisely with a pencil inside the screw holes (create an opening through the 3M tape, if needed), and on the edges of the latch and stud assemblies.
3. Remove the backing of the 3M tape to expose the adhesive surface.
4. Set each piece in place.
5. Carefully bring the component the stud will be mounted on to verify alignment and that the component will intersect without interference.
6. Once this is complete, drill a small pilot hole in the center of the hole opening. Or, remove each component after setting and marking. Then drill the pilot holes in the marked location.
7. Reattach the components with the 3M tape in the marked location.
8. Insert the oval, counter-sink screws. Note: screw length based on the depth of the fiberglass/aluminum the screws will be entering.

- ONE (1) WALK-THRU WINDSHIELD LATCH

- 3M BACKING TAPE

### Required, but not included

- FOUR (4) STAINLESS-STEEL MOUNTING SCREWS (LENGTH DETERMINED BY DEPTH OF MOUNTING SURFACES)

- PENCIL

- ELECTRIC DRILL AND PILOT HOLE DRILL BIT

